

Trac-Com V4 Instructions

Power On/Off:

- Press and hold the power button for 3 seconds
- Pressing the button temporarily will illuminate the screen but will not power cycle the unit

Adjusting Volume:

- Both users have an individual volume control located on each side of the unit.
- The volume is adjustable from 0 to 12 using the press + or - buttons.
- Listening to loud volumes can permanently affect your hearing. This device is capable of creating sound that is loud enough to cause harm. Please use caution while using the Trac-Com V4

Connecting Headsets:

- Insert the male connector found on the Trac-Com accessory into either female port on top of the Trac-Com V4, making sure to line up the notch on the male connector with the indentation on the female port.
- To disconnect a headset, press and hold the black button on the male connector while pulling it out of the unit.

Dual Battery System - Overview:

- The Trac-Com V4 is equipped with a Dual Battery System
- The Internal Battery is a 1500 mAh Li-Ion battery, rechargeable Via USB C cable
- This model is also compatible with a standard 9V battery, offering supplemental power.
- The Trac-Com V4 can be powered exclusively using the internal battery without a 9V installed, reducing the weight and operating cost.

9V Battery Logic:

- The Trac-Com V4 will default to using the 9V battery when installed. The readout will show 4 Bars of the full battery along with a 9V icon.
- As the 9V drains, the bars will drop down to zero.
- The system switches to the internal battery once the 9V battery is fully depleted. When using the internal battery, the screen will show a 3.7V icon.

Charging:

- To charge the Trac-Com V4, insert a powered USB-C cable into the unit
- Charge time for the internal battery is 2 hours